
Assembly Instruction Sheet #S-1042 P32 For Style 1042P32

is Required: Flathead acrevidiver, Philips screwidiver, plien, wire culture, whe strippers, electrical teps, safety glasses. it is deures: (1) 120v LED *90W DIMAMSI.E (4000K) it is deures: (2) 120v LED *90W DIMAMSI.E (4000K) it is deures: 17 Time: 10-20 inhules had been the Time: 10-20 inhules particularly and tespect all particular beginning installation. Check package content but and diagrams below to be sure all particular are particular to assemble, install, or operate the titure. Context customer service for replacement.

△Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a floansed electricism if in doubt. These instructions are provided for your safety. It is very important you read fram completely before installing the fidure. We strongly recommend that a licensed, professional electricism perform the installation.

Disconnect fixture from power source before replacing bufbs. Make sure bufbs are given sufficient time to cool before removal.



A Pass the supply wires through the Crossber (EE) Attach the Crossber (EE) to the Outlet Box (CC) STEP 2 - Attach Croseber to Outlet Box. ecure it with Outlet Box with the head of the Green Ground Screw facing you. ghien until enug (not included).

Supply Wires with Outlet Box Screws Ground Wire 8

Hardware Contents DESCRIPTION QUANTITY Outlet Box Screw Sectrical Marrets 8 8

用品的需

₹

PART

STEP 3 — Fit Calling Canopy to Crossber Assembly Figure 2

A. Fit the ceiling canopy to Mounting Screws (DD) and secure with Decorative Caps (AA). Note: The ceiling canopy should be anug against the ceiling and the Decorative Caps (AA). If not, adjust the length of the Mounting Screws (DD) by unscrewing the Hex Nut and Lock Washer and then screwing Mounting Screws (DD) in or out of the Crossbar (EE) until the orrect length is achieved.

and Hex Nuts to Crossber.
A. Line up a set of holes on the

(H) and Hotes

BTEP 1 - Attach Mounti

Screws, Lock Washers

Once the ceiling canopy is secure, remove the Decorative Caps (AA) and ceiling canopy and proceed to Step 4.

A. Use standard wire commediate (not included) to make all wire commediate. Twist commediate until wires are tightly joined togeth with season commediate with approved electrical tape and carefully wing each commediate wires into the Curlet Box. STEP 4 - Wire Connections from outlet box outlet box (or Red) Black wire from White wire Bars, or Green Ground wife from outlet box from outlet box Bere, or Green Ground with Figure 4 on the Crossber Green Ground Screw White wire from thouse Ground wire from fodure Ground wire from fluture from fluture A. Carefully tack all wires into the outlist box and position the oeiling camopy of the Fature Body (4) over the outlist box. Agg the holes in the oeiling camopy with the Mounting Servere (DD).
Secure with Decorative Caps (AA) and hand fighten until anuq. STEP 5 - Install Calling Canopy to Calling Figure 6 ₹ Canapy

on the ceiling campy.
Thread Mounting Screws (DD) iand lighten until anug luts onto the Mounting nto the holes on the seber (EE). Page Lock shere and thread Hex

Figure 1

Figure 3

ġ

ReleasedDate:2017-08-14