

Assembly Instruction Sheet #IS-1246P39 For Style 1246P39

Total Weight: Fritted enclosures, Fritted enclosure, glass, wire outlet, wire edgebar, electrical tape, safety glasses.
Light Source: 120V LED MAX (1W GU24).
Estimated Assembly Time: 30-40 minutes.
Precautions: Identify and inspect all parts before beginning installation. Check package content list and diagrams later to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.

Warnings and Cautions
 Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.

Package Contents	STEP 1 - Release Greenbar from Ceiling Canopy.															
<p>A Fixture Body x1</p> <p>B Middle Rod B1 4"x2pcs B2 6"x2pcs B3 12"x10pcs</p> <p>C Ceiling Canopy x1</p>	<p>1 Glass x3</p> <p>2 Glass x2</p> <p>3 Glass x2</p> <p>4 Glass x2</p> <p>5 Glass x2</p> <p>6 Glass x2</p>															
Hardware Contents	STEP 2 - Install Rods to Fixture Body.															
<table border="1"> <thead> <tr> <th>PART</th> <th>DESCRIPTION</th> <th>QUANTITY</th> </tr> </thead> <tbody> <tr> <td>BB</td> <td>Wire nut</td> <td>2pcs</td> </tr> <tr> <td>CC</td> <td>Screw</td> <td>2pcs</td> </tr> <tr> <td>BB</td> <td></td> <td></td> </tr> <tr> <td>CC</td> <td></td> <td></td> </tr> </tbody> </table>	PART	DESCRIPTION	QUANTITY	BB	Wire nut	2pcs	CC	Screw	2pcs	BB			CC			<p>Figure 1</p> <p>Figure 2</p>
PART	DESCRIPTION	QUANTITY														
BB	Wire nut	2pcs														
CC	Screw	2pcs														
BB																
CC																

<p>STEP 3 - Attach Mounting bracket to Outlet Box A. Pass the supply wires through the Mounting bracket(EE). Attach the Mounting bracket (EE) to the Outlet Box with the head of the Green Ground Screw (CC). Secure it with Outlet Box Screws (CC). Tighten until snug.</p> <p>Figure 3</p>	<p>STEP 4 - Wire Connections A. Use standard wire connectors to make all wire connections. Twist connectors and wires are tightly joined together. Wrap each connection with approved electrical tape and carefully stuff all the connector wires into the Outlet Box.</p> <p>Figure 4</p>
<p>STEP 5 - Install Ceiling Canopy to Ceiling</p> <p>Figure 5</p>	<p>STEP 6 - Install Glass.</p> <p>Figure 6</p>