



Cast Iron Sink Installation Guide

Item: CV-MONGO

NOTE: It is recommended that a licensed plumber or contractor install this item to maintain warranty.

1. Place the mounting bracket(s) in the installation location and mark the wall through each of the mounting holes.

Important: The sink should be anchored to two wall studs. Locate and mark the position of the wall studs to which you will fasten your sink by listening for a solid sound as you knock on the wall or by using a stud finder. If the studs in your room do not line up to the mounting location for your sink, wood blocking can be installed between the studs using standard 2 x 4's. We recommend consulting a professional if you are unfamiliar with this type of installation.

2. Drill mounting holes for the anchor or lag bolts using the guides created in the previous step. If the wall is tile, use a masonry drill bit.
3. Secure the mounting bracket(s) to the wall with the anchor bolts. After inserting the first fastener, verify that the bracket(s) is level. When the bracket(s) is properly aligned insert the remaining fasteners.
4. Install the new faucet and drain assembly according to the installation instructions.
5. Attach the sink and brackets to the wall with the mounting hardware.

Note: Some wall-mount sinks include a trim piece to cover the plumbing lines. These typically attach directly to the wall framing with lag bolts.

6. Connect the water supply and drain lines. Turn on the water supply to check for any leaking from the water supply lines or sink basin.

Drain Not Included: Please follow drain installation when installing the drain.