

## Assembly Instruction Sheet #IS-CDT1719 For Styles CDT1719BN and CDT1719OZ

Please go to www.quoizel.com for product cleaning tips. Go to the Care + Maintenance selection. Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses. Light Source: (4) A19 Medium Base Bulbs 100W Maximum. Estimated Assembly Time: 30-45 minutes Preparation: Identify and inspectall parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts. A Warnings and Cautions Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. E Cage Package Contents STEP 2 - Installing the Crossbar to x 1 **Outlet Box** Outlet Box A. Pass the supply wires through the Crossbar (AA). Attach the Crossbar AA (AA) to the Outlet Box with the head of Socket Outlet Box the Green Ground Screw facing you. A Assembly Screws (not Secure the Crossbar (AA) with Outlet x 1 included) Box Screws (not included). Tighten Supply Wires until snug. with Ground Wire Shade F Figure 2 Stem x 1 x 1 Shade Holder G STEP 3 - Test Fit the Ceiling Canopy to the Mounting Screws x 1 Hex Nut С x 3 Cap A. Place the ceiling canopy and Socket Assembly (A) onto the Н x 1 Shade Stop Mounting Screws (DD) and secure with Mounting Balls (EE). Note: D x 1 Finial The ceiling canopy and Socket Assembly (A) should be snug 1 x 1 against the ceiling and held tight with the Mounting Balls (EE). If it is not, adjust the length of the Mounting Screws (DD) on the Lock Washer Hardware Contents Crossbar (AA) by unscrewing the Hex Nut (CC) and Lock Washer RR x 2 (BB) and then screwing the mounting screws (DD) in or out of the Crossbar (AA) until the correct Crossbar Hex Nut CC x 1 length is achieved. Once the x 2 ceiling canopy and Socket Mounting Screw AA Assembly (A) is secure, DD x 2 remove the Mounting Balls Hex Nut and (EE) and Socket Assembly (A) Lock Washer Mounting Ball EE and proceed to Step 4. x 2 DD STEP 1 - Attach Mounting Screws, Lock Washers and Hex Nuts to Figure 3 Crossbar EE PP A. Line up a set of holes on the Crossbar (AA) and Holes on the **STEP 4 - Wire Connections** AA Ceiling Canopy of Socket Assembly (A). Thread Mounting A. Use standard wire connectors (not included) to make all wire Screws (DD) into the holes on connections. Twist connectors until wires are tightly joined together. the Crossbar (AA). Pass Lock DD Wrap each connection with approved electrical tape and carefully Washers (BB) and thread Hex stuff all the connected wires into the Outlet Box. AA Nuts (CC) onto the Mounting RR Screws (DD). Hand tighten until CC White wire snug. White wire from supply А from fixture Black wire Black wire from from fixture supply (or Red) W Ground wire Ground wire Figure 1 from supply from fixture Figure 4 Thank you for purchasing a Quoizel product. Need assistance with parts or assembly? Call Quoizel customer service at 1-800-645-3184 or visit us on-line at www.quoizel.com Released Date: 2016-10-08 © 2016 Quoizel Inc.

