

Assembly Instruction Sheet #IS-PCSB5012C For Style PCSB5012C

 $Please go to {\color{red} www.quoizel.com} for product cleaning tips. Go to the {\color{red} Care + Maintenance} selection.$

Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses.

Light Source: (12) Clear G9 Xenon Bulbs 40W Maximum (supplied)

Estimated Assembly Time: 30-45 minutes

Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, install, or operate the fixture. Contact customer service for replacement parts.


△ Warnings and Cautions

Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.

These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.


Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal.

Do not touch the bulb with bare hands use a cloth or glove.



STEP 1 - Install Ceiling Canopy, Rods and Fixture Body together


- A. Determine the Rods (C/D) to be assembled to the Fixture Body (F) according to your hanging height.
- B. Pass the supply wires and ground wire through the chosen rods (C/D) and the Ceiling Canopy (E). Thread the Fixture Body (F), the



© 2017 Quoizel Inc.


STEP 2 – Install the Crossbar to the junction box

A. Attach the Crossbar (A) to the Outlet Box with the head of the Green Ground Screw facing you. Secure it with Outlet Box Screws (not included), tighten until snug.



STEP 3 - Making the Wire Connections


A. Use standard wire connectors (not included) to make all wire connections. Twist connectors until wires are tightly joined together. Wrap each connection with approved electrical tape and carefully stuff all the connected wires into outlet box.



Thank you for purchasing a Quoizel product. Need assistance with parts or assembly? Call Quoizel customer service at 1-800-645-3184 or visit us on-line at www.quoizel.com

STEP 4 - Attach Ceiling Canopy to Crossbar

A. Line up the holes on the side of the Ceiling Canopy (E) to the mounting holes on the Crossbar (A). Secure them with Mounting Screws (B). Tighten until sung.



STEP 5 - Install Bulbs and Shades

- A. Insert bulbs (H) onto sockets and push snugly into place.

 IMPORTANT: Do not touch the bulb with bare hands use a cloth or glove.
- B. Thread Shades (G) onto sockets and hand tighten gently until snug.

Your fixture is now assembled and ready to use. Enjoy!




Figure 5

